

Aquagard Showerseal Kit

DESCRIPTION OF PRODUCT

SHOWERSEAL is a two part waterproofing system consisting of a cementitious powder blend and a Styrene Butadiene liquid latex which is used for sealing of shower bases and walls.

GENERAL PRODUCT INFORMATION

- Appearance: Powder has a grey cement like resemblance and the liquid is viscous milky white
- Packaging: A 10 litre bucket containing a First coat 3,2kg kit, a Second coat 2,5kg kit and polypropylene membrane 100mmx5m
- Storage: Shelf life is 12 months in sealed and unopened containers. Product should be stored out of direct sunlight with temperature range between 5-35 degrees C.
- Specific Gravity: Liquid 1.0 and powder 2.0

AREAS OF USE

- Existing shower bases and walls
- New shower bases and walls
- Fish ponds and water features
- Rising damp treatment

PRODUCT FEATURES

- Easy to use
- Can be applied to damp and green surfaces
- Non toxic. Suitable for fish and potable water
- Tiles can be bonded directly onto the waterproofing
- Can withstand permanent damp conditions and immersion in water

APPLICATION INSTRUCTIONS

- Lightly wet surfaces to be waterproofed using a spray bottle or brush.
- Ensure that all surfaces are clean and as smooth as possible. The First Coat Kit should now be mixed. Using the 10 litre bucket supplied, pour the liquid into the bucket. Slowly pour the powder into the bucket and keep mixing until it has reached a creamy consistency. The membrane which is supplied is used to reinforce the wall floor joint. It is 100mm wide, so that it will turn 50mm up onto wall and lap 50mm onto floor. A heavy coat of mixed Shower Seal should be applied to wall floor joint. The membrane should immediately be applied into the wet substrate and saturated from the top using liberal amounts of the Shower Seal compound. If the surface is too rough and there are voids, then a portion of Shower Seal to be poured out and mixed with some plaster sand to bulk out the compound. This can be applied by brush to all the rough areas. No drying time is necessary and the membrane can be applied straight over.
- Once the membrane has been laid, the rest of the mixture must be liberally applied to the rest of the floor and walls. Try fill all voids to create as smooth a surface as possible as this will make the tiling job much easier.

- After a drying period of 4-5 hours, or when initial set has occurred, the Second Coat Kit can be mixed up as per the first mix. It is a slightly smaller pack, as saturation of the membrane has already been done. Once again this should be applied as liberally as possible, to fill hollows and unevenness, but at the same time avoid forming any lumps on the surface.

COVERAGE

One kit will cover a shower base 1-1,5 m² in size

USEFUL APPLICATION TIPS

- The use of latex or yellow kitchen rubber gloves when applying the Showerseal is recommended. The product is extremely difficult to remove from ones hands and extensive scrubbing with a scouring pad is required to clean up.
- Tools or brushes must be washed straight away after use with clean water. Brushes which have been allowed to get hard will have to be thrown away. Turps or Xylene can be used to soften the dried product on tools if it has become hard.

DISCLAIMER

Whilst Aquagard makes every effort to ensure that all information given is accurate, the use and application of our products is outside our direct or continuous control, therefore Aquagard cannot accept any direct or indirect liability arising from the use of our products. Aquagard is able to supply a manufacturers guarantee on request. Please contact the Aquagard consultant for further information.

HEALTH AND SAFETY

Please read the product label, technical data sheet and material safety data sheet before use. Do not ingest internally. Avoid contact with eyes. If solution does come into contact with eyes, flush immediately with water and refer to Doctor for medical attention. Avoid prolonged contact with skin or breathing in of mist or fumes. Wear a suitable face mask. Keep out of reach of children. Take due care and precaution when applying the product especially if working at heights.



Tel: 011 794 3307 | info@aquagard.co.za | aquagard.co.za
Unit 5 Task Park, Mailship Road, Laser Park, Roodepoort 2040